

# Features include:

Compatible with 1,2,3,4 and 5 channel button versions of the DecoFlex WireFree™ RTS wall switch which offers customizable buttons for easy organization and personalization.

Available in both silver and black finishes.

Features rubber non-slip feet.

Hand-held or table top use.



Table Top  
or  
Hand-Held use

---

# Easy to Assemble!

The battery-powered DecoFlex WireFree™ RTS Wall Switch easily converts to a table top or hand-held control. Simply place the DecoFlex WireFree™ wall switch base assembly into the DecoFlex WireFree™ RTS Table Top Accessory and secure with included screws.



Top of DecoFlex WireFree™ RTS  
Table Top accessory

Standard DecoFlex WireFree™ RTS  
switch base assembly

Base of DecoFlex WireFree™ RTS  
Table Top accessory

---